




707U Parts List

UNIT / PARTS LIST



REF. NO.	DESCRIPTION	707U Assembly P/N 35686-001C	707U-UK Assembly P/N 35686-002C
1	Discharge Dome	40	40
2	Motor Cover	252413-001	252413-001
3	Retainer Clip (4)	19	19
4	Motor Base	352728-001	352728-001
5	Diffusing Screen	45	45
6	Impeller	D-9P	D-9P
7	Set Screw, Cup	M3	M3
8	Impeller Pump, Molded	8A	8A
9	Vibration Dampener	90	90
10	Center Pan	35P	35P
11	Center Pan Support (4)	23	23
12	Drip Tube (2)	27	27
13	Speed Clip (2)	37	37
14	Float & Valve Assembly	92P	92P
15	Motor 115V	252596-001	-
15A	Motor 220V	-	252596-002
16	Mounting Bracket	186	186
17	Extension Nozzle	53	53
18	Humidistat (not shown)	352680-002C	352680-002C
19	Saddle Valve, Self-Tapping (not shown)	IN-25T	IN-25T
20	Bezel	54	54
21	Junction Box	175	175
22	Junction Box Cover	177-00	177-00
23	Adapter Plate	253122-001	253122-001
24	Grounding Plate	250867-001	-
25	Nomex Insulator	-	152619-001
26	Terminal Block Mounting Plate	-	252846-001
27	Terminal Block	-	348341-003



Courtesy of
Cigar and Wine Stuff
www.cigarandwinestuff.com